




we  clean

User Guide

Vax Careline: (UK) 0844 412 8455
(ROI) 1-800 928 308

Bagless Upright



Get Cleaning...

What's your Vax's model number?

e.g. U89-MAF

What's your serial number? (Located on the base of the machine)


Note these down in case you need them in future. Please keep instructions for further use.

vax.co.uk

U89-MAF series


Machine Overview

- 1 Handle
- 2 Handle height adjuster
- 3 Dirt bin release button
- 4 Carry handle
- 5 Power on/off button
- 6 Inner cyclones
- 7 Dirt bin
- 8 Hose
- 9 Hose to machine connector
- 10 Height adjustment
- 11 Hose to extension tube connector
- 12 Handle cord hook (for attaching the cord when the machine is in use)
- 13 Handle release button
- 14 TurboTool caddy
- 15 Upper cord hook
- 16 3-in-1 crevice, upholstery and dusting brush tool
- 17 Cord
- 18 Lower cord hook



Unit


Accessories



- 19 Telescopic extension tube
- 20 TurboTool (some models only)

- 21 Hard floor tool (some models only)
- 22 Pre-motor filter

Filters



- 23 HEPA H12 post motor filter/
HEPA H12 Antibacterial post
motor filter
(dependent on model)

General Safety Information

FOR HOUSEHOLD USE ONLY.

When using the vacuum cleaner, basic safety precautions should always be observed, including the following:

1. Only use the vacuum cleaner indoors on dry surfaces.
2. Turn off the vacuum cleaner controls before disconnecting or connecting from the mains supply.
3. Always unplug the vacuum cleaner before connecting or disconnecting the vacuum hose and accessories.
4. Children should be supervised to ensure that they do not play with the appliance.
5. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
6. Use only as described in this manual. Use only Vax recommended attachments.
7. Do not use the vacuum cleaner if it has been dropped, damaged, left outdoors or dropped into water. Do not use the vacuum cleaner with a damaged cord or plug. If the supply cord is damaged, it must be replaced by the manufacturer or a recommended Service Agent to avoid hazard and invalidating the guarantee.
8. Do not pull or carry by cord/hose. Do not use the cord/hose as a handle, close a door on the cord/hose or pull cord/hose around sharp edges or corners. Do not run the vacuum cleaner over the cord/hose. Keep the cord away from heated surfaces.
9. Do not handle the plug or vacuum cleaner with wet hands. Do not use outdoors or on wet surfaces.
10. Do not put any objects into openings. Do not use with any openings blocked and do not restrict airflow. Keep all openings free of dust, lint, hair or anything that might reduce airflow.
11. Keep hair, loose clothing, fingers and all parts of the body away from openings and moving parts.
12. Do not pick up hot coals, cigarette butts, matches or any hot, smoking or burning objects.
13. Do not pick up flammable or combustible materials (lighter fluid, petrol, kerosene etc.) or use in the presence of explosive liquids or vapours.
14. Do not vacuum up harmful or toxic material (chlorine, bleach, ammonia, drain cleaner etc.).
15. Do not vacuum up hard or sharp objects such as glass, nails, screws, coins, etc.
16. Do not use without ALL of the filters in place.
17. Take extra care when vacuuming on stairs.
18. Keep vacuuming area well lit.
19. Store the vacuum cleaner in a cool, dry area.
20. Turn off the on/off switch before unplugging the vacuum cleaner
21. Use only CE-approved 13 amp extension cords. Non-approved cords may overheat. Care should be taken to arrange the cord so that the cord cannot be tripped over.



WARNING: Always switch off and unplug the vacuum cleaner from the electrical outlet before assembling, opening or emptying the dirt container, or before connecting/disconnecting the attachments.



CAUTION: The vacuum cleaner is a very powerful unit. Before plugging the cord into the electrical outlet, make sure the switch is in the 'off' position.



IMPORTANT: If the inlet, hose or telescopic tube is blocked, switch off the vacuum cleaner and remove the blockage(s) before re-starting the vacuum cleaner. See Maintenance; Clearing Blockages.



IMPORTANT: Cleaning filters improves vacuum performance. Vax recommends that your filters should be checked and cleaned periodically. If your filters are washable make sure they are completely dry before inserting back into the vacuum cleaner.




IMPORTANT: The motor is equipped with a thermal cut-out. If for any reason the unit should overheat, the thermostat will automatically turn the unit off. Should this occur, unplug the vacuum cleaner from the electrical outlet and turn off the switch. Remove dirt container and empty. Clean filters. Allow the unit to cool for approximately one (1) hour. To re-start, plug into an electrical outlet and switch back on.

This vacuum cleaner is intended for household use only and NOT for commercial or industrial use.

PLEASE KEEP INSTRUCTIONS FOR FURTHER USE.

Operation



Keep your Vax like new




IMPORTANT: The condition of the filters affects the performance of your machine. Please check and clean filters periodically (depending on the level of use). For full cleaning instructions, see page 6.

IMPORTANT: Do not use the vacuum cleaner without all of the filters in place.


Assembling your vacuum cleaner




Operating the appliance




Twist cord hook to release cord.




Adjust handle height.




Plug into mains.



Turn unit on.



Recline unit by pressing foot on front of unit.



In upright position turn height adjustment to desired setting. High setting for high carpet pile and hard floors. Low setting for low carpet pile.

IMPORTANT: When the vacuum cleaner is stood in the upright position or when using the hose and tools, the carpet height adjustment must be set to the highest position.

NOTE: Vax recommends that you raise the height of the brushbar to the highest position when using this cleaner on lino and hard flooring due to constant rotation. Vax cannot be held responsible for damage to these surfaces if the customer fails to take notice of this recommendation.

Operation


Using accessories

NOTE: The 3-in-1 tool and TurboTool can be attached to the telescopic tube or hose directly.


NOTE: The hard floor tool can ONLY be attached to the telescopic tube.

NOTE: To change setting on your 3-in-1 tool press in the Vax logo located at the top of the tool.



Attaching to hose



Press the latch release on the hose before removing.




Choose an accessory.




Attach accessory to hose ensuring the latch secures the accessory.


Attaching to telescopic extension tube




Remove telescopic extension tube.



Attach hose to telescopic extension tube ensuring the latch secures the hose.




Attach accessory to telescopic extension tube.









Hard floor tool can only be attached to telescopic tube.

Maintenance (Keep your Vax as good as new)

Emptying and cleaning the dirt container




Cleaning the HEPA pre-motor filter




Maintenance (Keep your Vax as good as new)

Advanced filter cleaning



Cleaning the post-motor filter **WARNING:** Do not wash the post-motor filter.




Maintenance (Keep your Vax as good as new)

Removing blockages


WARNING: To reduce the risk of electric shock, turn the vacuum cleaner off and unplug from the electrical outlet before performing maintenance/troubleshooting checks.

Disconnect the hose from the vacuum cleaner and remove any blockages found then reconnect the hose securely.


Removing blockages from the brushbar




Unscrew the 4 screws on the base of unit.



Remove cover of floor nozzle.




Lift the brushbar out of its position.




Remove the belt from the end of the brushbar.


Removing blockages from the TurboTool (Not standard on all models)



Turn the TurboTool over and slide off the locking ring.



Pivot lowering housing and remove clog.



To re-assemble, be sure that the tabs are engaged. Pivot the lower housing closed. Slip the locking ring into the groove at the neck of the TurboTool to complete reassembly.

FAQs



WARNING: to reduce the risk of personal injury, unplug the vacuum cleaner before performing maintenance/troubleshooting checks.

Is there an accessory missing?

- Check the 'Machine Overview' page in this guide to make sure the part is definitely included in your unit.
- If it is missing, we're here to help. Simply call us on **0844 412 8455**

What do I do if an accessory/the unit becomes damaged or broken?

- Visit **vax.co.uk** for parts and spares.
- Please call our Vax careline to purchase new spares or order a replacement: **0844 412 8455**

Why won't the vacuum cleaner pick up?

- The filters may be clogged: Refer to the Maintenance sections (page 6).
- The dirt container is full or blocked: Refer to the Maintenance sections (page 6).
- The dirt container may be incorrectly installed: Refer to the Maintenance sections (page 6).
- The brushbar may be blocked. Refer to the maintenance section (page 7).

Why won't the accessories pick up properly?

- The accessory may be blocked: Refer to the maintenance section (page 8).
- The accessory may be faulty: call our Vax Careline to order a replacement: **0844 412 8455**

Why is dust escaping from the vacuum?

- The filters may not be installed correctly. Refer to the Maintenance sections (page 6).
- The dirt container may be incorrectly installed: Remove the dirt container from the unit by pressing the dirt container release button (page 6) and reattach it to the unit, ensuring it is locked firmly back into place.
- The filters may be clogged: Refer to the Maintenance sections (page 6).

Why will the vacuum cleaner not run?

- It may not be plugged into the electrical outlet correctly. Ensure that the plug is pushed into the electrical outlet securely.
- The electrical outlet may not be working. Check the fuse or breaker and consult an electrician.
- The motor thermostat may have tripped. Switch off and unplug the vacuum cleaner. Leave for one hour before switching the vacuum cleaner back on.



we  to help

Don't take me back to the shop, simply call us

(UK) 0844 412 8455
(ROI) 1-800 928 308

vax.co.uk
vaxireland.ie

This does not affect your statutory rights

Other Information

Service & Help

Vax Careline:

(UK) 0844 412 8455

(ROI) 1-800 928 308

Monday-Friday 8.30am to 6.30pm

Saturday-Sunday 9.00am to 5.00pm

If you have any queries about using your Vax, call the Vax Careline. Please make a note of the serial number and model number of your product before calling. For the nearest Service Agent, please call the Vax Customer Careline or visit **vax.co.uk**

Consumables

To purchase spares and accessories, please visit **vax.co.uk**

U89-MAF series pre motor filter (Filter type B):	1-7-130852-00
U89-MAF series post motor filter:	1-7-130812-00
U89-MAF series belt:	1-1-130909-00

Technical Specification

Voltage:	220-240V ~50Hz
Wattage:	1600 W
Capacity:	3L
Filters:	Pre-motor filter (washable) HEPA H12 post-motor filter (tap to clean) (dependent on model) HEPA H12 Antibacterial post-motor filter (tap to clean) (dependent on model)
Cord length:	10m
Weight:	7.8kg (dependent per model)

Subject to technical change without notice.



Other Information

EEC Statement of Compliance

Manufacturer/EEC importer: Vax Limited, hereby on our own responsibility, declare that the U89-MAF series is manufactured in compliance with the following Directives:

Safety: 2006/95/EC Low Voltage Directive

EMC: 2004/108/EC Electromagnetic Compatibility Directive



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.



Vax Ltd., Kingswood Road, Hampton Lovett, Droitwich, Worcestershire, WR9 OQH, UK
email: info@vax.co.uk - website: vax.co.uk

Version 1.0